

FORMING FACT



BIERSCHBACH EQUIPMENT & SUPPLY

1101 S LYONS AVE
SIOUX FALLS, SD 57101
1-800-843-3707



3030 N PLAZA DRIVE
RAPID CITY, SD 57709
1-800-658-5437

2121 LEECH AVE
SIOUX CITY, IA 51106
1-800-243-3707

4001 MAIN AVE
FARGO, ND 58103
1-800-540-2760

ADJUSTABLE RECTANGULAR COLUMN FORM

The Adjustable Rectangular Column Form is adjustable for columns up to 30" square, in 1" increments with the exception of 28" and 29" dimensions. For columns 27" or less in either or both cross-section dimensions, column sizes are accommodated by placing the panels in a "Run-by" manner. Tightening wedges are the only additional hardware required. Three-quarter inch holes must be drilled through the plywood at the appropriate connecting bolt slot in the cross member. Outside corners and/or standard panels and fillers may be used in conjunction with the Adjustable Rectangular Column Form. For 30" square column, four outside corners are required.



A combination of standard panels and/or fillers are normally used in conjunction with four outside corners on even inch dimensioned columns of 24" or less.

Column hinges will facilitate gang forming columns. See complete description of both the Column Hinges and the Adjustable Rectangular Column Form in the Component Section.

